

DABIT-005 (Cocaine Test)

www.fieldforensics.com



1) Remove Sampler from clear tube.

2) Remove paper tab from **Sticky Sampler Tip**. **DO NOT TOUCH** sticky sampler tip.



3) **Dab** sticky Sampler Tip on the suspect material. **Dab firmly** to collect a sample of suspect material.

4) **Return Sampler** to Clear Inner Tube, Sampler tip first, and close.



5) Hold Sampler as shown. **Squeeze Clear Inner Tube AND Sampler Tube** to break ampoule.

6) Keeping the **Sampler Tip pointed downward**, look for a color change on the **Sampler Tip** and compare to the color chart below. Observe for 60 seconds; if no color then the test is negative.



Possible Irritant:
Avoid contact of liquids with eyes and mucous membranes.

May 2014 Rev. 8

FIELD FORENSICS INC.

DABIT-005

Cocaine Test

Control	Cocaine / Crack	PCP
		

DABIT-005: Cocaine Reagent

Full DABIT™ Color Chart Available at www.fieldforensics.com