

# DABIT-004 (LSD Test)

[www.fieldforensics.com](http://www.fieldforensics.com)



**1) Remove Sampler**  
from clear tube.

**2) Remove** paper tab  
from **Sticky Sampler**  
**Tip. DO NOT TOUCH**  
sticky sampler tip.



**3) Dab** sticky Sampler Tip  
on the suspect material.  
**Dab firmly** to collect a  
sample of suspect material.

**4) Return Sampler**  
to Clear Inner  
Tube, Sampler tip  
first, and close.



**5) Hold Sampler** as  
shown. **Squeeze Clear**  
**Inner Tube AND**  
**Sampler Tube** to  
**break ampoule.**

**6) Keeping the Sampler Tip**  
**pointed downward**, look for a  
color change on the **Sampler Tip**  
and compare to the color chart  
below. Observe for 60 seconds; if  
no color then the test is negative.



**Possible Irritant:**  
**Avoid contact of liquids with eyes and**  
**mucous membranes.**

*April 2015 Rev. 8*

# FIELD FORENSICS INC.

## DABIT-004

### *LSD Test*

Control

LSD

Psilocybin



DABIT-004: LSD Reagent

Full DABIT™ Color Chart Available at [www.fieldforensics.com](http://www.fieldforensics.com)