

DABIT-006 (Marijuana Test)

www.fieldforensics.com



1) Remove Sampler
from clear tube.

2) Remove paper tab
from **Sticky Sampler**
Tip. DO NOT TOUCH
sticky sampler tip.



3) Dab sticky Sampler Tip
on the suspect material.
Dab firmly to collect a
sample of suspect material.

4) Return Sampler
to Clear Inner
Tube, Sampler tip
first, and close.



5) Hold Sampler as
shown. **Squeeze Clear**
Inner Tube AND
Sampler Tube to
break ampoule.

6) Keeping the Sampler Tip
pointed downward, look for a
color change on the **Sampler Tip**
and compare to the color chart
below. Observe for 60 seconds; if
no color then the test is negative.



Possible Irritant:

**Avoid contact of liquids with eyes and
mucous membranes.**

December 2015 Rev. 9

FIELD FORENSICS INC.

DABIT-006

Marijuana Test

Control



Marijuana /
Hashish /
THC



DABIT-006: Marijuana Reagent
(marijuana, hashish, THC)

Full DABIT™ Color Chart Available at www.fieldforensics.com